



OPERATOR'S AND PARTS MANUAL

GRAPPLE BUCKETS



PALADIN
LIGHT CONSTRUCTION GROUP



The Power of Combined Excellence



FOR COMPACT TRACTORS

SERIAL NUMBER: _____

MODEL NUMBER: _____

Manual Number: OM721
Part Number: 75621

TABLE OF CONTENTS

PREFACE	3
SAFETY PRECAUTIONS	
SAFETY STATEMENTS	5
GENERAL SAFETY PRECAUTIONS	5-7
EQUIPMENT SAFETY PRECAUTIONS	8
DECALS	
DECAL PLACEMENT	9
DECALS	10
INSTALLATION AND OPERATION	11-12
MAINTENANCE AND SERVICE	
LUBRICATION	13
CYLINDER SEAL REPLACEMENT	14-15
SPECIFICATIONS	
SCRAP GRAPPLE SPECIFICATIONS	16
BRUSH GRAPPLE SPECIFICATIONS	17
BOLT TORQUE SPECIFICATIONS	18
LIMITED WARRANTY	19
PARTS	
48" SCRAP GRAPPLE ASSEMBLY	20-21
48" BRUSH GRAPPLE ASSEMBLY	22-23
54" BRUSH GRAPPLE ASSEMBLY	24-25
72" BRUSH GRAPPLE ASSEMBLY	26-27
CYLINDER ASSEMBLY #106808	28-29
CYLINDER ASSEMBLY #107174	30-31
OPTIONAL CUTTING EDGE ASSEMBLIES (48" SCRAP GRAPPLE)	32-33

**THIS PAGE
IS INTENTIONALLY
BLANK**

PREFACE

GENERAL COMMENTS

Congratulations on the purchase of your new BRADCO product! This product was carefully designed and manufactured to give you many years of dependable service. Only minor maintenance (such as cleaning and lubricating) is required to keep it in top working condition. Be sure to observe all maintenance procedures and safety precautions in this manual and on any safety decals located on the product and on any equipment on which the attachment is mounted.

This manual has been designed to help you do a better, safer job. Read this manual carefully and become familiar with its contents.

WARNING!  Never let anyone operate this unit without reading the "Safety Precautions" and "Operating Instructions" sections of this manual. Always choose hard, level ground to park the vehicle on and set the brake so the unit cannot roll.

Unless noted otherwise, right and left sides are determined from the operator's control position when facing the attachment.

NOTE: The illustrations and data used in this manual were current (according to the information available to us) at the time of printing, however, we reserve the right to redesign and change the attachment as may be necessary without notification.

BEFORE OPERATION

The primary responsibility for safety with this equipment falls to the operator. Make sure the equipment is operated only by trained individuals that have read and understand this manual. If there is any portion of this manual or function you do not understand, contact your local authorized dealer or the manufacturer.

SAFETY ALERT SYMBOL



This is the "Safety Alert Symbol" used by this industry. This symbol is used to warn of possible injury. Be sure to read all warnings carefully. They are included for your safety and for the safety of others working with you.

SERVICE

When servicing your product, remember to use only manufacturer replacement parts. Substitute parts may not meet the standards required for safe, dependable operation.

To facilitate parts ordering, record the model and serial number of your unit in the space provided on the cover of this manual. This information may be obtained from the identification plate located on the product.

The parts department needs this information to insure that you receive the correct parts for your specific model.

**THIS PAGE
IS INTENTIONALLY
BLANK**

SAFETY STATEMENTS



THIS SYMBOL BY ITSELF OR WITH A WARNING WORD THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY OR THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.



DANGER

THIS SIGNAL WORD IS USED WHERE SERIOUS INJURY OR DEATH WILL RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.



WARNING

THIS SIGNAL WORD IS USED WHERE SERIOUS INJURY OR DEATH COULD RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.



CAUTION

THIS SIGNAL WORD IS USED WHERE MINOR INJURY COULD RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.

NOTICE

NOTICE INDICATES A PROPERTY DAMAGE MESSAGE.

GENERAL SAFETY PRECAUTIONS

WARNING!

READ MANUAL PRIOR TO INSTALLATION



Improper installation, operation, or maintenance of this equipment could result in serious injury or death. Operators and maintenance personnel should read this manual, as well as all manuals related to this equipment and the prime mover thoroughly before beginning installation, operation, or maintenance. **FOLLOW ALL SAFETY INSTRUCTIONS IN THIS MANUAL AND THE PRIME MOVER'S MANUAL(S).**



READ AND UNDERSTAND ALL SAFETY STATEMENTS

Read all safety decals and safety statements in all manuals prior to operating or working on this equipment. Know and obey all OSHA regulations, local laws, and other professional guidelines for your operation. Know and follow good work practices when assembling, maintaining, repairing, mounting, removing, or operating this equipment.



KNOW YOUR EQUIPMENT

Know your equipment's capabilities, dimensions, and operations before operating. Visually inspect your equipment before you start, and never operate equipment that is not in proper working order with all safety devices intact. Check all hardware to ensure it is tight. Make certain that all locking pins, latches, and connection devices are properly installed and secured. Remove and replace any damaged, fatigued, or excessively worn parts. Make certain all safety decals are in place and are legible. Keep decals clean, and replace them if they become worn or hard to read.

GENERAL SAFETY PRECAUTIONS

WARNING!



PROTECT AGAINST FLYING DEBRIS

Always wear proper safety glasses, goggles, or a face shield when driving pins in or out, or when any operation causes dust, flying debris, or any other hazardous material.

WARNING!



LOWER OR SUPPORT RAISED EQUIPMENT

Do not work under raised booms without supporting them. Do not use support material made of concrete blocks, logs, buckets, barrels, or any other material that could suddenly collapse or shift positions. Make sure support material is solid, not decayed, warped, twisted, or tapered. Lower booms to ground level or on blocks. Lower booms and attachments to the ground before leaving the cab or operator's station.


WARNING!



USE CARE WITH HYDRAULIC FLUID PRESSURE

Hydraulic fluid under pressure can penetrate the skin and cause serious injury or death. Hydraulic leaks under pressure may not be visible. Before connecting or disconnecting hydraulic hoses, read your prime mover's operator's manual for detailed instructions on connecting and disconnecting hydraulic hoses or fittings.

- Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.
- If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.
- Wear safety glasses, protective clothing, and use a piece of cardboard or wood when searching for hydraulic leaks. **DO NOT USE YOUR HANDS!** **SEE ILLUSTRATION.**



GENERAL SAFETY PRECAUTIONS

WARNING!



DO NOT MODIFY MACHINE OR ATTACHMENTS

Modifications may weaken the integrity of the attachment and may impair the function, safety, life, and performance of the attachment. When making repairs, use only the manufacturer's genuine parts, following authorized instructions. Other parts may be substandard in fit and quality. Never modify any ROPS (Roll Over Protection Structure) or FOPS (Falling Object Protective Structure) equipment or device. Any modifications must be authorized in writing by the manufacturer.

WARNING!



SAFELY MAINTAIN AND REPAIR EQUIPMENT

- Do not wear loose clothing or any accessories that can catch in moving parts. If you have long hair, cover or secure it so that it does not become entangled in the equipment.
- Work on a level surface in a well-lit area.
- Use properly grounded electrical outlets and tools.
- Use the correct tools for the job at hand. Make sure they are in good condition for the task required.
- Wear the protective equipment specified by the tool manufacturer.



SAFELY OPERATE EQUIPMENT

Do not operate equipment until you are completely trained by a qualified operator in how to use the controls, know its capabilities, dimensions, and all safety requirements. See your machine's manual for these instructions.

- Keep all step plates, grab bars, pedals, and controls free of dirt, grease, debris, and oil.
- Never allow anyone to be around the equipment when it is operating.
- Do not allow riders on the attachment or the prime mover.
- Do not operate the equipment from anywhere other than the correct operator's position.
- Never leave equipment unattended with the engine running, or with this attachment in a raised position.
- Do not alter or remove any safety feature from the prime mover or this attachment.
- Know your work site safety rules as well as traffic rules and flow. When in doubt on any safety issue, contact your supervisor or safety coordinator for an explanation.

EQUIPMENT SAFETY PRECAUTIONS

WARNING! KNOW WHERE UTILITIES ARE



Observe overhead electrical and other utility lines. Be sure equipment will clear them. When digging, call your local utilities for location of buried utility lines, gas, water, and sewer, as well as any other hazard you may encounter.



OPERATING THE GRAPPLE BUCKET

- Do not mount this attachment onto any prime mover that exceeds 40 HP, 4000 pounds operating weight OR 2000 pounds lifting capacity.
- Do not exceed the lifting capacity of your prime mover.
- Operate only from the operator's station.
- When operating on slopes, drive up and down, not across. Avoid steep hillside operation, which could cause the prime mover to overturn.
- Reduce speed when driving over rough terrain, on a slope, or turning, to avoid overturning the vehicle.
- An operator must not use drugs or alcohol, which can change his or her alertness or coordination. An operator taking prescription or over-the-counter drugs should seek medical advice on whether or not he or she can safely operate equipment.
- Before exiting the prime mover, lower the attachment to the ground, turn off the prime mover's engine, remove the key and apply the brakes.
- Never heap load heavy material where the combined weight of the bucket and material could exceed the rated lifting capacity of the loader.
- Be sure the load does not stick out too far in front of the bucket. A light load sticking out too far can have the same tipping effect as a heavy load carried in close.
- When using the grapple, lift the load slightly and make sure that the load is secure. If the load appears to be unstable, lower the load, open the grapple and reposition the load to attain full stability.



TRANSPORTING THE GRAPPLE BUCKET

- Travel only with the attachment in a safe transport position to prevent uncontrolled movement. Drive slowly over rough ground and on slopes.
- When driving on public roads use safety lights, reflectors, Slow Moving Vehicle signs etc., to prevent accidents. Check local government regulations that may affect you.
- Do not drive close to ditches, excavations, etc., cave in could result.
- Do not smoke when refueling the prime mover. Allow room in the gas tank for expansion. Wipe up any spilled fuel. Secure cap tightly when done.



MAINTAINING THE GRAPPLE BUCKET

- Before performing maintenance, lower the attachment to the ground, turn off the engine, remove the key and apply the brakes.
- Never perform any work on the attachment unless you are authorized and qualified to do so. Always read the operator service manual's before any repair is made. After completing maintenance or repair, check for correct functioning of the attachment. If not functioning properly, always tag "DO NOT OPERATE" until all problems are corrected.
- Worn, damaged, or illegible safety decals must be replaced. New safety decals can be ordered from BRADCO.
- Never make hydraulic repairs while the system is under pressure. Serious personal injury or death could result.
- Never work under a raised attachment.

11002 5-29-07


DECALS

DECAL PLACEMENT


GENERAL INFORMATION

The diagram on this page shows the location of the decals used on the BRADCO Scrap and Brush Grapples. The decals are identified by their part numbers, with reductions of the actual decals located on the following pages. Use this information to order replacements for lost or damaged decals. Be sure to read all decals before operating the attachment. They contain information you need to know for both safety and longevity.

BRUSH GRAPPLES



SCRAP GRAPPLES



IMPORTANT: Keep all safety signs clean and legible. Replace all missing, illegible, or damaged safety signs. When replacing parts with safety signs attached, the safety signs must also be replaced.

REPLACING SAFETY SIGNS: Clean the area of application with nonflammable solvent, then wash the same area with soap and water. Allow the surface to fully dry. Remove the backing from the safety sign, exposing the adhesive surface. Apply the safety sign to the position shown in the diagram above and smooth out any bubbles.

10993 5-10-07

DECALS



DANGER! PINCH POINT
PART #40149



MADE IN U.S.A.
PART #4338



BRADCO LOGO
PART #40179



WARNING! HIGH PRESSURE FLUID
PART #50-0725



WARNING! POWER UNIT LIMITATIONS
PART #40967

INSTALLATION AND OPERATION

GENERAL INFORMATION

These BRADCO Brush and Scrap grapples were designed to be used on Compact Tractors and other prime movers up to 40 horsepower with a maximum of 4000 pounds operating weight and 2000 pounds lifting capacity. Operating this attachment on a prime mover that exceeds any of these specifications will cause damage to the attachment and void all warranties.

Due to the various different compact tractors and loaders that these attachments can be mounted on, the buckets are shipped without the hydraulic hoses and couplers. These can be purchased from your local dealer.

HOSE REQUIREMENTS

Power and return hoses and couplers must be purchased from your dealer to install the attachment onto your loader. The hoses must be long enough to accommodate for complete roll out of the bucket, rated for the maximum hydraulic pressure of your loaders hydraulic system and a minimum of .25" in diameter.

The hoses must also be equipped with a 6FJX end to connect to the grapple bucket and the couplers must mate up to the auxiliary hydraulic couplers on your loader.

INSTALLATION

Install the bucket by following your tractor and loader operator's manual for installing an attachment.

WARNING!  **To Avoid Serious Personal Injury, make sure the bucket is securely latched to the attachment mechanism of your unit. Failure to do so could result in separation of the bucket from the unit.**

Install the power and return hoses (purchased from your dealer) to the fittings on the grapple bucket followed by the quick couplers. Connect the hydraulic quick couplers to the auxiliary hydraulics and route the hoses in such a fashion as to prevent chafing and pinching and secure in place wherever necessary.

Start engine and slowly cycle the bucket cylinder(s) several times to purge system of air, check for proper hydraulic connection, hose routing, and hose length. **NOTE: Power and return hoses must be long enough to accommodate complete rollout of the bucket.**

Check the attachment for proper assembly, installation, and hydraulic leaks.

DETACHING

On firm level ground, close the grapple and lower the loader arms until the attachment is on the ground.

Turn off the engine. Move the control levers back and forth to relieve pressure in the line. Disconnect couplers.

NOTE: Connect couplers together or install caps to prevent contaminants from entering the hydraulic system.

Follow your tractor and loader operator's manual for detaching (removing) an attachment.

INSTALLATION AND OPERATION

NOTE: Frequent lubrication of grease fittings at the end of the cylinder(s) and pivot points with a multi-purpose grease will greatly increase life of the product.

OPERATION

All scrap grapple and brush grapple buckets are designed to pick up bulky, unusually shaped, or long materials that would not stay in an ordinary bucket.

1. Approach the load in such a fashion that the weight will be centered on the floor of the bucket. The heaviest side should be closest to the back of the bucket and not near the bucket edge.
2. Before lifting, make certain the bucket is completely under the load and the bucket floor is level.
3. Close the grapples to their fullest extent possible and lift the bucket slightly to be certain that the load is secure.

NOTE: If the load appears to be unstable, lower the bucket to the ground, open the grapples and reposition the load to attain full stability. Repeat until full stability is achieved.

When using the grapples as a rake to drag materials into position for pick up, THE GRAPPLES MUST BE COMPLETELY OPEN.

NOTICE: Applying a raking-type force to partially open grapples will greatly magnify the fluid pressure in the hydraulic hoses, fittings, and cylinder(s) which may cause component failure.

STORAGE

1. Clean the unit thoroughly, removing all mud, dirt, and grease.
2. Inspect for visible signs of wear, breakage, or damage. Order any parts required and make the necessary repairs to avoid delays when starting next season.
3. Tighten loose nuts, capscrews, and hydraulic connections.
4. Cap hydraulic couplers to protect against contaminants.
5. Touch up all unpainted surfaces with paint, to prevent rust.
6. Coat the exposed portions of the cylinder rods with grease.
7. Store the unit in a dry and protected place. Leaving the unit outside will materially shorten its life.

MAINTENANCE & SERVICE

GENERAL INFORMATION

Regular maintenance is the key to long equipment life and safe operation. Maintenance requirements have been reduced to the absolute minimum. However, it is very important that these maintenance functions be performed as described below.

DAILY

- Check all bolts and nuts for tightness.
- Replace any missing bolts or nuts with approved replacement parts.
- Check hydraulic system for hydraulic oil leaks. See procedure below.
- Visually inspect the machine for worn parts or cracked welds, and repair as necessary.

EVERY 40 HOURS


- Lubricate all grease fittings.

WARNING! Escaping fluid under pressure can have sufficient force to penetrate the skin, causing serious personal injury. Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than hands, to search for suspected leaks.



Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.

If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.



IMPORTANT: When replacing parts, use only factory approved replacement parts. Manufacturer will not claim responsibility for use of unapproved parts or accessories, and/or other damages as a result of their use.

MAINTENANCE AND SERVICE

CYLINDER SEAL REPLACEMENT


The following information is provided to assist you in the event you should need to repair or rebuild a hydraulic cylinder. When working on hydraulic cylinders, make sure that the work area and tools are clean and free of dirt to prevent contamination of the hydraulic system and damage to the hydraulic cylinders. Always protect the active part of the cylinder rod (the chrome section). Nicks or scratches on the surface of the rod could result in cylinder failure. Clean all parts thoroughly with a cleaning solvent before reassembly.

DISASSEMBLY PROCEDURE

IMPORTANT: Do not contact the active surface of the cylinder rod with the vise. Damage to the rod could result.


RETAINING RING TYPE GLAND

1. Mount the cylinder tube securely in a vise. **NOTICE: Do not clamp too tight and distort the tube.**
2. Rotate the gland with a spanner wrench (available from your dealer), until the gland retaining ring appears in the milled slot.



Pry up the end of the gland retaining ring with a pointed tool. Rotate the gland with a spanner wrench while removing the retaining ring. **NOTE: The gland and piston seal(s) can be pulled out and cut as they appear in the milled slot during disassembly. After cutting, pull them on out through the milled slot.**

3. Pull the cylinder rod from the cylinder tube.




4. Inspect the piston and the bore of the cylinder tube for deep scratches or galling. If damaged, the piston and cylinder tube must be replaced.
5. Remove the hex nut, piston, flat washer or spacer tube (if so equipped), and gland from the cylinder rod. If the cylinder rod is rusty, scratched, or bent, it must be replaced.
6. Remove and discard all old seals.

ASSEMBLY PROCEDURE

IMPORTANT: Replace all seals even if they do not appear to be damaged. Failure to replace all seals may result in premature cylinder failure.

1. Install the cylinder rod seal in the gland first. Be careful not to damage the seal in the process as it is somewhat difficult to install. A special installation tool is available to help with installing the seal. Simply fit the end of the tool over the seal so that the large prong of the tool is on the outside of the seal, and the two smaller prongs on the inside. The lip of the seal should be facing towards the tool. Rotate the handles on the tool around to wrap the seal around the end of the tool.



10530 3-8-06

MAINTENANCE AND SERVICE



Now insert the seal into the gland from the inner end. Position the seal in its groove, and release and remove the tool. Press the seal into its seat the rest of the way by hand.

NOTE: Threaded gland is shown in diagram for reference only.

2. Install the new piston ring, rod wiper, O-rings, and backup washers, if applicable, on the piston. Be careful not to damage the seals. Caution must be used when installing the piston ring. The ring must be stretched carefully over the piston with a smooth, round, pointed tool.





2. Slide the gland onto the cylinder rod being careful not to damage the rod wiper. Then install the spacer, or flat washer (if so equipped), small O-ring, piston, and hex nut onto the end of the cylinder rod.

3. Secure the cylinder rod (mounting end) in a vise, with a support at its center. Torque the nut to the amount shown on the chart for the thread diameter of the cylinder rod. (see chart)



Thread Diameter	POUNDS - FEET
7/8"	150-200
*1"	230-325
1-1/8"	350-480
1-1/4"	490-670
1-3/8"	670-900

*** 1" Thread Diameter WITH 1.25" Rod Diameter**
Min. 230 ft. lbs. Max. 250 ft. lbs.



IMPORTANT: Do not contact the active surface of the cylinder rod with the vise. Damage to the rod could result.

IMPORTANT: Ensure that the piston ring fits squarely into the cylinder tube and piston groove, otherwise the ring may be damaged and a leak will occur.

4. Apply a lubricant (such as Lubriplate #105) to the piston and teflon ring. Insert the cylinder rod assembly into the cylinder tube.

5. Rotate the gland with a spanner wrench until the hole (drilled into the retaining slot of the gland) appears in the milled slot of the cylinder tube. Insert the hooked end of the gland retaining rod into the hole.

Rotate the gland until the gland retaining rod forms a ring between the gland and the cylinder tube. When complete, the bent end of the gland retainer ring should be hidden (not turned so it is exposed in the slot) to prevent it from popping out.



WARNING!



Cylinders serviced in the field are to be tested for leakage prior to the attachment being placed in work. Failure to test rebuilt cylinders could result in damage to the cylinder and/or the attachment, cause severe personal injury or even death.

SPECIFICATIONS

48" SCRAP GRAPPLES





DESCRIPTION	48"
A. Overall Width	48.00"
B. Overall Height	25.00"
C. Overall Length	31.00"
Grapple Opening	29.00"
Operating Pressure (PSI)	1500-2500
Weight (lbs)	380#
Cylinder Specifications	
Bore	2.00"
Stroke	4.50"
Rod Diameter	1.25"
SPECIFICATIONS AND DESIGN ARE SUBJECT TO CHANGE WITHOUT NOTICE AND WITHOUT LIABILITY THEREFOR.	

11005 5-30-07 6-8-06

SPECIFICATIONS

48", 54" & 72" BRUSH GRAPPLES



DESCRIPTION	48"	54"	72"
A. Overall Width	48.00"	54.00"	72.00"
B. Overall Height	25.50"	25.50"	25.63"
C. Overall Length	30.45"	30.45"	30.45"
Grapple Opening	29.00"	29.00"	29.00"
Operating Pressure (PSI)	1500-2500	1500-2500	1500-2500
Weight (lbs)	287#	295#	385#
Cylinder Specifications			
Bore	1.62"	1.62"	1.62"
Stroke	44.50"	4.50"	4.50"
Rod Diameter	1.12"	1.12"	1.12"
SPECIFICATIONS AND DESIGN ARE SUBJECT TO CHANGE WITHOUT NOTICE AND WITHOUT LIABILITY THEREFOR.			

BOLT TORQUE

BOLT TORQUE SPECIFICATIONS

GENERAL TORQUE SPECIFICATION TABLE

Use the following torques when special torques are not given. These values apply to fasteners as received from suppliers, dry, or when lubricated with normal engine oil. They do not apply if special graphited or moly disulphide greases or other extreme pressure lubricants are used. This applies to both UNF and UNC threads. Remember to always use grade five or better when replacing bolts.

IMPORTANT: On all PLATED GRADE 8 bolts, reduce torque 15% from listed bolt torque specification.

SAE Grade No.		2				5				8*			
Bolt head identification marks as per grade. NOTE: Manufacturing Marks Will Vary													
		TORQUE		TORQUE		TORQUE		TORQUE		TORQUE		TORQUE	
Bolt Size		Pounds Feet		Newton-Meters		Pounds Feet		Newton-Meters		Pounds Feet		Newton-Meters	
Inches	Millimeters	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.
1/4	6.35	5	6	7	8	9	11	12	15	12	15	16	20
5/16	7.94	10	12	14	16	17	20.5	23	28	24	29	33	39
3/8	9.53	20	23	27	31	35	42	48	57	45	54	61	73
7/16	11.11	30	35	41	47	54	64	73	87	70	84	95	114
1/2	12.70	45	52	61	70	80	96	109	130	110	132	149	179
9/16	14.29	65	75	88	102	110	132	149	179	160	192	217	260
5/8	15.88	95	105	129	142	150	180	203	244	220	264	298	358
3/4	19.05	150	185	203	251	270	324	366	439	380	456	515	618
7/8	22.23	160	200	217	271	400	480	542	651	600	720	814	976
1	25.40	250	300	339	406	580	696	787	944	900	1080	1220	1464
1-1/8	25.58	-	-	-	-	800	880	1085	1193	1280	1440	1736	1953
1-1/4	31.75	-	-	-	-	1120	1240	1519	1681	1820	2000	2468	2712
1-3/8	34.93	-	-	-	-	1460	1680	1980	2278	2380	2720	3227	3688
1-1/2	38.10	-	-	-	-	1940	2200	2631	2983	3160	3560	4285	4827

* Thick Nuts must be used with Grade 8 bolts

METRIC BOLT TORQUE SPECIFICATIONS

Size of Screw	Grade No.	Coarse Thread			Fine Thread		
		Ptich (mm)	Pounds Feet	Newton-Meters	Pitch (mm)	Pounds Feet	Newton-Meters
M6	5.6	1.0	3.6-5.8	4.9-7.9	-	-	-
	8.8		5.8-4	7.9-12.7		-	-
	10.9		7.2-10	9.8-13.6		-	-
M8	5.6	1.25	7.2-14	9.8-19	1.0	12-17	16.3-23
	8.8		17-22	23-29.8		19-27	25.7-36.6
	10.9		20-26	27.1-35.2		22-31	29.8-42
M10	5.6	1.5	20-25	27.1-33.9	1.25	20-29	27.1-39.3
	8.8		34-40	46.1-54.2		35-47	47.4-63.7
	10.9		38-46	51.5-62.3		40-52	54.2-70.5
M12	5.6	1.75	28-34	37.9-46.1	1.25	31-41	42-55.6
	8.8		51-59	69.1-79.9		56-68	75.9-92.1
	10.9		57-66	77.2-89.4		62-75	84-101.6
M14	5.6	2.0	49-56	66.4-75.9	1.5	52-64	70.5-86.7
	8.8		81-93	109.8-126		90-106	122-143.6
	10.9		96-109	130.1-147.7		107-124	145-168
M16	5.6	2.0	67-77	90.8-104.3	1.5	69-83	93.5-112.5
	8.8		116-130	157.2-176.2		120-138	162.6-187
	10.9		129-145	174.8-196.5		140-158	189.7-214.1
M18	5.6	2.0	88-100	119.2-136	1.5	100-117	136-158.5
	8.8		150-168	203.3-227.6		177-199	239.8-269.6
	10.9		175-194	237.1-262.9		202-231	273.7-313
M20	5.6	2.5	108-130	146.3-176.2	1.5	132-150	178.9-203.3
	8.8		186-205	252-277.8		206-242	279.1-327.9
	10.9		213-249	288.6-337.4		246-289	333.3-391.6

10360 6-8-95-2

Limited Warranty

Except for the Excluded Products as described below, all new products are warranted to be free from defects in material and/or workmanship during the Warranty Period, in accordance with and subject to the terms and conditions of this Limited Warranty.

1. Excluded Products. The following products are excluded from this Limited Warranty:

(a) Any cable, part that engages with the ground (i.e. sprockets), digging chain, bearing, teeth, tamping and/or demolition head, blade cutting edge, pilot bit, auger teeth and broom brush that either constitutes or is part of a product.

(b) Any product, merchandise or component that, in the opinion of Paladin Light Construction¹, has been (i) misused; (ii) modified in any unauthorized manner; (iii) altered; (iv) damaged; (v) involved in an accident; or (vi) repaired using parts not obtained through Paladin Light Construction.

2. Warranty Period. The Limited Warranty is provided only to those defects that occur during the Warranty Period, which is the period that begins on the first to occur of: (i) the date of initial purchase by an end-user, (ii) the date the product is first leased or rented, or (iii) the date that is six (6) months after the date of shipment by Paladin Light Construction as evidenced by the invoiced shipment date (the "Commencement Date") and ends on the date that is twenty-four (24) months after the Commencement Date.

3. Terms and Conditions of Limited Warranty. The following terms and conditions apply to the Limited Warranty hereby provided:

(a) Option to Repair or Replace. Paladin Light Construction shall have the option to repair or replace the product.

(b) Timely Repair and Notice. In order to obtain the Limited Warranty, (i) the product must be repaired within thirty (30) days from the date of failure, and (ii) a claim under the warranty must be submitted to Paladin Light Construction in writing within thirty (30) days from the date of repair.

(c) Return of Defective Part or Product. If requested by Paladin Light Construction, the alleged defective part or product shall be shipped to Paladin Light Construction at its manufacturing facility or other location specified by Paladin Light Construction, with freight PRE-PAID by the claimant, to allow Paladin Light Construction to inspect the part or product.

Claims that fail to comply with any of the above terms and conditions shall be denied.

LIMITATIONS AND EXCLUSIONS.

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTY BASED ON A COURSE OF DEALING OR USAGE OF TRADE.


IN NO EVENT SHALL PALADIN LIGHT CONSTRUCTION BE LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES.

IN NO EVENT SHALL PALADIN LIGHT CONSTRUCTION BE LIABLE FOR ANY LOSS OR CLAIM IN AN AMOUNT IN EXCESS OF THE PURCHASE PRICE, OR, AT THE OPTION OF PALADIN LIGHT CONSTRUCTION, THE REPAIR OR REPLACEMENT, OF THE PARTICULAR PRODUCT ON WHICH ANY CLAIM OF LOSS OR DAMAGE IS BASED. THIS LIMITATION OF LIABILITY APPLIES IRRESPECTIVE OF WHETHER THE CLAIM IS BASED ON BREACH OF CONTRACT, BREACH OF WARRANTY, NEGLIGENCE OR OTHER CAUSE AND WHETHER THE ALLEGED DEFECT IS DISCOVERABLE OR LATENT.

¹Attachment Technologies Inc., a subsidiary of Paladin Brands Holding, Inc. (PBHI) is referred to herein as Paladin Light Construction.

48" SCRAP GRAPPLE

ASSEMBLY #108605




48" SCRAP GRAPPLES

ASSEMBLY #108605

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	106828	Cylinder Guard
2	1	1339	.50" UNF X 1.25" Hex Capscrew
3	1	1505	.50" Lock Washer
4	2	1516	.50" Flat Washer
5	1	30383	Straight Connector 6FJX-6MJ with .0625 Orifice
6	2	3285	Cap
7	1	106808	Cylinder Assembly
8	5	6616	Grease Fitting
9	1	106814	Cylinder Pin - 5.13" Long - Rod End
10	1	2005476	Cylinder Pin - 5.50" Long - Barrel End
11	5	1048	.38" UNC X 2.25" Hex Capscrew
12	5	1837	.38" UNC Deformed Lock Nut
13	2	1027	.31" UNC X 2.25" Hex Capscrew
14	2	1502	.31" Lock Washer
15	2	103184	Top Hose Clamp Plate
16	2	103181	Hose Clamp
17	1	106810	Grapple
18	3	2005471	Grapple Pin - 4.25" Long
19	1	106809	Bucket

48" BRUSH GRAPPLE

ASSEMBLY #108597



48" BRUSH GRAPPLES


ASSEMBLY #108597

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	106828	Cylinder Guard
2	1	1339	.50" UNF X 1.25" Hex Capscrew
3	1	1505	.50" Lock Washer
4	1	1516	.50" Flat Washer
5	1	107181	Spacer Tube
6	2	3285	Cap
7	1	3434	90° Elbow 6MBo-6MJ
8	1	30259	90° Elbow 6MBo-6MJ with .060 Orifice
9	1	107174	Cylinder Assembly
10	5	6616	Grease Fitting
11	1	106814	Cylinder Pin - 5.13" Long - Rod End
12	1	2005476	Cylinder Pin - 5.50" Long - Barrel End
13	5	1048	.38" UNC X 2.25" Hex Capscrew
14	5	1837	.38" UNC Deformed Lock Nut
15	1	106810	Grapple
16	3	2005471	Grapple Pin - 4.25" Long
17	1	108599	Bucket

10988 5-29-07

54" BRUSH GRAPPLE

ASSEMBLY #108598




54" BRUSH GRAPPLES

ASSEMBLY #108598

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	106828	Cylinder Guard
2	1	1339	.50" UNF X 1.25" Hex Capscrew
3	1	1505	.50" Lock Washer
4	1	1516	.50" Flat Washer
5	1	107181	Spacer Tube
6	2	3285	Cap
7	1	3434	90° Elbow 6MBo-6MJ
8	1	30259	90° Elbow 6MBo-6MJ with .060 Orifice
9	1	107174	Cylinder Assembly
10	5	6616	Grease Fitting
11	1	106814	Cylinder Pin - 5.13" Long - Rod End
12	1	2005476	Cylinder Pin - 5.50" Long - Barrel End
13	5	1048	.38" UNC X 2.25" Hex Capscrew
14	5	1837	.38" UNC Deformed Lock Nut
15	1	106810	Grapple
16	3	2005471	Grapple Pin - 4.25" Long
17	1	108600	Bucket

72" BRUSH GRAPPLE

ASSEMBLY #108415




72" BRUSH GRAPPLES

ASSEMBLY #108415

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	2	106828	Cylinder Guard
2	2	1339	.50" UNF X 1.25" Hex Capscrew
3	2	1505	.50" Lock Washer
4	2	1516	.50" Flat Washer
5	2	107181	Spacer Tube
6	2	3434	90° Elbow 6MBo-6MJ
7	2	30259	90° Elbow 6MBo-6MJ with .060 Orifice
8	2	107174	Cylinder Assembly
9	8	6616	Grease Fitting
10	2	38472	Hose .25" x 40.5" 6FJX-6FJX
11	2	38518	Hose .25" x 34" 6FJX-6FJX
12	2	3498	Tee 6MJ-6MJ-6MJ
13	2	3285	Cap
14	2	2005476	Cylinder Pin - 5.50" Long - Barrel End
15	8	1048	.38" UNC X 2.25" Hex Capscrew
16	8	1837	.38" UNC Deformed Lock Nut
17	2	106814	Cylinder Pin - 5.13" Long - Rod End
18	1	108416	Bucket
19	2	34118	Rubber Edge (10")
20	2	1021	.31" UNC X .75" Hex Capscrew
21	2	1502	.31" Lock Washer
22	1	108501	Hydraulic Cover
23	1	108479	Right Grapple
24	4	2005471	Grapple Pin - 4.25" Long
25	1	108478	Left Grapple

CYLINDER ASSEMBLY

ASSEMBLY #106808



CYLINDER ASSEMBLY

ASSEMBLY #106808


<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	106812	Cylinder Rod
2	1	57330	Cylinder Gland
3	1	106811	Cylinder Tube
4	1	52644	Washer
5	1	88431	Piston
6	1	1482	Hex Nut (Torque to 150-200 ft. lbs.)
7	1	4974*	Rod Wiper
8	1	7164*	Cylinder Gland Retaining Ring
9	1	45219	Poly Pak Seal
10	1	4634 *	Back-Up Washer
11	1	4633*	O'Ring
12	1	4635*	O'Ring
13	1	4637*	O'Ring
14	1	4636*	Piston Ring

NOTE: All parts marked with an asterisk(*) are included in Seal Kit #45136. Parts are not sold separately.

10585 5-30-06

CYLINDER ASSEMBLY

ASSEMBLY #107174



CYLINDER ASSEMBLY

ASSEMBLY #107174


<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	107176	Cylinder Rod
2	1	50547	Cylinder Gland
3	1	107175	Cylinder Tube
4	1	52644	Washer
5	1	50546	Piston
6	1	1482	Hex Nut (Torque to 150-200 ft. lbs.)
7	1	4981*	Rod Wiper
8	1	4579*	Back-Up Washer
9	1	4580*	O'Ring
10	1	8177*	Cylinder Gland Retaining Ring
11	1	4988*	Back-Up Washer
12	1	4987*	O'Ring
13	1	4635*	O'Ring
14	1	4985*	O'Ring
15	1	4984*	Piston Ring

NOTE: All parts marked with an asterisk(*) are included in Seal Kit #4990. Parts are not sold separately.

10583 5-30-06

OPTIONAL CUTTING EDGE ASSEMBLIES

48" SCRAP GRAPPLE



11008 5-30-07

OPTIONAL CUTTING EDGE ASSEMBLIES
48" SCRAP GRAPPLE

SINGLE BEVEL BOLT-ON CUTTING EDGE ASSEMBLY #107158

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	5	1841	.50" UNC Deformed Oval Lock Nut
2	5	1646	.50" Hard Flat Washer
3	5	10120	.50" UNC X 1.75" Plow Bolt
4	1	106813	48" Cutting Edge - Single Bevel

DOUBLE BEVEL BOLT-ON CUTTING EDGE ASSEMBLY #105866

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	5	1841	.50" UNC Deformed Oval Lock Nut
2	5	1646	.50" Hard Flat Washer
3	5	10120	.50" UNC X 1.75" Plow Bolt
5	1	105857	48" Cutting Edge - Double Bevel