



Product Bulletin

How To Hook A Shaver Driver Up To A Skid Steer

A high flow skid steer allows the dealer to mount a Shaver Driver without a skid steer kit.

The supply line should be coupled to the supply line on the skid steer via a **flat face coupler**.

There are three steps to follow in order to determine which way works most efficiently with the host skid steer:

- 1) Attach the primary return line to the return side of the high flow via a **flat face coupler**. **If the driver does not free fall, then there is still too much restriction on the return coupler. Move on to **Step 2**.
- 2) Locate the "**power beyond**" plug on the valve body. It is simply a plug or stop turned into the top of the valve body. Add a third line out of the location of the plug and couple it to the case drain line on the skid steer. **If the driver does not free fall, then there is still too much restriction between the two return couplers.
- 3) Remove the couplers from the case drain line on both the skid steer and the implement and place a **pipe fitting** with no restriction. This will allow the machine to free fall in use. However, this makes the process of attaching and unhooking the implement more difficult.

Please follow the three steps listed above in order to reduce the amount of hardware needed to attach the driver with each use. There is not a kit available for this process; the lines and couplers will need to be sourced at the dealer level.