


PARTS MANUAL

609 & 611 POWER BACKHOES



Limited Warranty

Except for the Excluded Products as described below, all new products are warranted to be free from defects in material and/or workmanship during the Warranty Period, in accordance with and subject to the terms and conditions of this Limited Warranty.

1. <u>Excluded Products</u>. The following products are <u>excluded</u> from this Limited Warranty:

(a) Any cable, part that engages with the ground (i.e. sprockets), digging chain, bearing, teeth, tamping and/or demolition head, blade cutting edge, pilot bit, auger teeth and broom brush that either constitutes or is part of a product.

(b) Any product, merchandise or component that, in the opinion of Paladin Light Construction¹, has been (i) misused; (ii) modified in any unauthorized manner; (iii) altered; (iv) damaged; (v) involved in an accident; or (vi) repaired using parts not obtained through Paladin Light Construction.

2. <u>Warranty Period</u>. The Limited Warranty is provided only to those defects that occur during the Warranty Period, which is the period that begins on the <u>first to occur</u> of: (i) the date of initial purchase by an end-user, (ii) the date the product is first leased or rented, or (iii) the date that is six (6) months after the date of shipment by Paladin Light Construction as evidenced by the invoiced shipment date (the "<u>Commencement Date</u>") and ends on the date that is <u>twenty-four (24) months</u> after the Commencement Date.

3. <u>Terms and Conditions of Limited Warranty</u>. The following terms and conditions apply to the Limited Warranty hereby provided:

(a) <u>Option to Repair or Replace</u>. Paladin Light Construction shall have the option to repair or replace the product.

(b) <u>Timely Repair and Notice</u>. In order to obtain the Limited Warranty, (i) the product must be repaired within thirty (30) days from the date of failure, and (ii) a claim under the warranty must be submitted to Paladin Light Construction in writing within thirty (30) days from the date of repair.

(c) <u>Return of Defective Part or Product</u>. If requested by Paladin Light Construction, the alleged defective part or product shall be shipped to Paladin Light Construction at its manufacturing facility or other location specified by Paladin Light Construction, with freight PRE-PAID by the claimant, to allow Paladin Light Construction to inspect the part or product.

Claims that fail to comply with any of the above terms and conditions shall be denied.

LIMITATIONS AND EXCLUSIONS.

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTY BASED ON A COURSE OF DEALING OR USAGE OF TRADE.

IN NO EVENT SHALL PALADIN LIGHT CONSTRUCTION BE LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES.

IN NO EVENT SHALL PALADIN LIGHT CONSTRUCTION BE LIABLE FOR ANY LOSS OR CLAIM IN AN AMOUNT IN EXCESS OF THE PURCHASE PRICE, OR, AT THE OPTION OF PALADIN LIGHT CONSTRUCTION, THE REPAIR OR REPLACEMENT, OF THE PARTICULAR PRODUCT ON WHICH ANY CLAIM OF LOSS OR DAMAGE IS BASED. THIS LIMITATION OF LIABILITY APPLIES IRRESPECTIVE OF WHETHER THE CLAIM IS BASED ON BREACH OF CONTRACT, BREACH OF WARRANTY, NEGLIGENCE OR OTHER CAUSE AND WHETHER THE ALLEGED DEFECT IS DISCOVERABLE OR LATENT.


¹Attachment Technologies Inc., a subsidiary of Paladin Brands Holding, Inc. (PBHI) is referred to herein as Paladin Light Construction.

TABLE OF CONTENTS

SERVICE PARTS

MAINFRAME ASSEMBLY. Mainframe Swing Post Swing Cylinder Stabilizers Hose Bundle Clamps	5	#87443		
·	EMBLY	#82623		
	EMBLY			
CONSOLE ASSEMBLY		#87442		
VALVE ASSEMBLY		#2232		
OPTIONAL SWING SPEED	CONTROL	#83337		
	BLY			
CYLINDERS				
SWING CYLINDER		#81022		
STABILIZER CYLINI	DER	#82980		
609 BOOM CYLIND	ER	#82625		
	ΞR			
609 DIPPER CYLINI	DER - SN #8289 & UP			
	UP TO SN #8289			
611 DIPPER CYLINI	DER - SN #8227 & UP			
	UP TO SN #8227			
BUCKET CYLINDEF	#117548			
HOSE SETS				
	SET			
609 BOOM & DIPPE	R HOSE SET	#82762		
611 BOOM & DIPPER HOSE SET#82				
STABILIZER PAD OPTION	S			
FLAT STABILIZER F	AD ASSEMBLY	#83055		
GROUSER STABILI	ZER PAD ASSEMBLY	#83054		
LARGE GROUSER	STABILIZER PAD ASSEMBLY	#83057		
RUBBER STABILIZE	ER PAD ASSEMBLY	#83056		
BUCKET OPTIONS	STANDARD	SEVERE DUTY		
12" BUCKET	#68212			
	#68216			
	#68218			
20" BUCKET	#68220	#85020		
24" BUCKET	#68224	#85024		
609 FIRST LINE RFPAIR K	ίΙΤ	#83758		
	IT			
609 DECALS		#40235		
		6878		

10-19-12-5




⁶⁻¹⁶⁻⁹⁹

ASSEMBLY #87443 MAINFRAME

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	1	37554	Hose .50" X 36" 8FJX 90° Short Gooseneck - 8FJX 90° Short Gooseneck
2	1	3327	Тее
3	2	3049	Bushing 12MP - 8FP
4	1	3273	Coupling 8FP-8FJX
5	1	3211	Close Nipple .50 NPT (Inline Filter)
	1	3309	Heavy Close Nipple .50 NPT x 4.00" (Check Valve)
6	1	45691	Check Valve (Hex)
7	2	3189	Square Head Plug
8	1	45132	Inline Filter (Round)
9	2	1010	.25" UNC X 2.75" Hex Capscrew
	2	81595	Spacer
	8	1512	.25" Flat Washer
	2	1501	.25" Lock Washer
	2	1224	.25" UNC Hex Nut
10	1	82609	Priority Flow Divider
11	1	3071	90° Adapter 8MP-8MJ
12	1	37690	Hose .50" X 41" (SN#10067 & UP)
			8FJX-8FJX 45° Gooseneck
	-	37577	Hose .50" X 39" 8FJX - 8FJX (UP TO SN#10067)
13	4	1043	.38" UNC X 1.00" Hex Capscrew
			(Pin retaining capscrews installed with Locktite Grade 242)
14	2	1514	.38" Flat Washer
15	2	81807	Spacer Tube
16	2	82423	Pin
	2	6616	Grease Zerk
17	1	82613	Thrust Washer 2.00 X .125"
18	2	1734	Snap Ring
19	2	82435	Bearing
20	1	82446	Mainframe (Includes (4) #83815 Bushings, (4) 82447 Bushings - Installed with Locktite Grade 680)
21	1	82090	Swing Lock Pin
22	As Req'd	82611	Thrust Washer 2.00" X .030"
	As Req'd	82612	Thrust Washer 2.00" X .060"
	As Req'd	82613	Thrust Washer 2.00" X .125"
23	3 '	1503	.38" Lock Washer
24	2	6799	Spacer
25	2	6186	Hose Clamp
26	2	82794	Bushing
27	2	1611	Cotter Pin .12 X 1.00"
28	1	82796	Linkage
29	1	1982	Shoulder Screw
30	4	6886	Rubber Bumper (Service Part ONLY)
	4	1542	.50" UNC Lock Nut
31	2	1226	.38" UNC Hex Nut
32	As Req'd	1528	.62" SAE Flat Washer
33	1	1666	Snap Ring

NOTE: Use thrust washers (Item #22) to adjust mainframe / swing post to minimum free play. 7728

ASSEMBLY #87443 SWING POST



7729 9-28-04-2


ASSEMBLY #87443 SWING POST

<u>NO</u>	REQ'D	PART NO.	DESCRIPTION
1	2	1043	.38" UNC X 1.00" Hex Capscrew (Installed with Locktite Grade 242)
2	2	1503	.38" Lock Washer
3	2	1514	.38" Flat Washer
4	2	81807	Spacer Tube
5	2	81847	Pin
6	1	82408	Swing Post (Includes (2) 82402 Bushings Installed with Locktite Grade 680)
7	1	82415 (1)	Pivot Pin
8	As Req'd	6623	Thrust Washer 1.38" X .031"
	As Req'd	64724	Thrust Washer 1.38" X .090"
	As Req'd	64725	Thrust Washer 1.38" X .125"
9	2	1650	Snap Ring
10	-	82402	Bushing (Included with Swing Post) (Installed with Locktite Grade 680)
11	1	82416	Pivot Pin
12	As Req'd	6622	Thrust Washer 1.75" X .082"
13	1	1651	Snap Ring
14	1	6616	Grease Zerk
15	1	1088	.50" UNC X 1.00" Hex Capscrew
16	1	1516	.50" Flat Washer
17	1	86149	Spacer Tube
18	1	1505	.50" Lock Washer

NOTE:

(1) Pivot Pin #82415 is sold only in Pin Kit #86306. Kit includes one pin #82415, two thrust washers #6623 and two snap rings #1650.

ASSEMBLY #87443 SWING CYLINDERS




ASSEMBLY #87443 SWING CYLINDERS

<u>NO</u>	REQ'D	PART NO.	DESCRIPTION
1	As Req'd	57693	Thrust Washer 1.25" X .078"
	As Req'd	64727	Thrust Washer 1.25" X .145"
2	-	62523	Self Aligning Bushing (Included in Swing Cylinder Assembly)
3	2	82827	Spacer
4	As Req'd	68057	Thrust Washer 1.50"
5	-	82441	Needle Bearing (Included in Swing Cylinder Assembly)
6	2	81022	Swing Cylinder Assembly (Includes (2) #82441 Needle Bearings and (1) #62523 Bushing)
	2	6616	Grease Zerk
	2	30164	Special LH Lateral Tee
7	4	53031	90° Grease Zerk
8	4	82420	Pin
9	4	1047	.38" UNC X 2.00" Hex Capscrew
10	4	1514	.38" Flat Washer
11	4	81595	Spacer Tube
12 13	4	1837 83815	.38" UNC Hex Lock Nut Bushing (Included in Mainframe - Installed with Locktite Grade 680)

MAINFRAME ASSEMBLY ASSEMBLY #87443

STABILIZERS



7733 6-16-99


ASSEMBLY #87443 STABILIZERS

<u>NO</u>	REQ'D	<u>PART NO.</u>	DESCRIPTION
1	8	1652	Snap Ring
2	As Req'd	57693	Thrust Washer 1.25" X .078"
	As Req'd	64727	Thrust Washer 1.25" X .145"
	As Req'd	64728	Thrust Washer 1.25" X .031"
3	4	82993 (1)	Pin
4	2	82980	Stabilizer Cylinder Assembly
	4	6616	Grease Zerk
5	-	82447	Bushing (Included in Mainframe - Installed
			with Locktite Grade 680)
6	2	82958	Stabilizer Arm
7	2	83233	Pin
8	2	1613	Cotter Pin .25" X 2.00"

NOTE:

(1) Pivot Pin #82993 is sold only in Pin Kit #86310. Kit includes one pin #82993, two thrust washers #64727 and two snap rings #1652.

HOSE BUNDLE CLAMPS



HOSE BUNDLE CLAMPS


UP TO SERIAL #---10065

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	2	1043	.38" UNC X 1.00" Hex Capscrew
2	1	84724	Right Hose Bundle Clamp
3	2	1837	.38" UNC Deformed Lock Nut
4	1	84718	Left Hose Bundle Clamp

SERIAL #---10065 AND UP

<u>NO</u>	REQ'D	<u>PART NO.</u>	DESCRIPTION
1	2	1043	.38" UNC X 1.00" Hex Capscrew
2	1	84718	Right Hose Bundle Clamp
3	2	1837	.38" UNC Deformed Lock Nut
4	1	84718	Left Hose Bundle Clamp

ASSEMBLY #82623



6829 8-20-98-4


ASSEMBLY #82623

NO	REQ'D	PART NO.	DESCRIPTION
1	-	6615	Self Aligning Bushing (Included in Cylinder Assembly)
2	1	85782	Dipper Cylinder Assembly
	2	6616	Grease Zerk
0	2 As Daald	3103	Straight Adapter
3	As Req'd	6623	Thrust Washer 1.38" X .031"
	As Req'd	64724	Thrust Washer 1.38" X .090"
	As Req'd	64725	Thrust Washer 1.38" X .125"
4	1	82625	Boom Cylinder Assembly
	1	6616	Grease Zerk
_	2	3103	Straight Adapter
5	1	1043	.38" UNC X 1.00" Hex Capscrew
		(=00	(Installed with Locktite Grade 242)
6	1	1503	.38" Lock Washer
7	1	82862	Clamp Plate
8	1	82863	Rubber Spacer
9	1	6616	Grease Zerk
10	-	86673	Bushing (Included in Boom Assembly)
11	1	82534 (1)	Pivot Pin
12	4	1650	Snap Ring
13	1	86634 (3)	Boom Lock Handle (Spring Pin Style)
14	1	86366 (3)	Boom Lock (Spring Pin Style)
	1	1972 (3)	Spring Pin
15	1	86048	Boom Assembly (Includes (2) 86673 & (2) 82552
	_		Bushings - Installed with Locktite Grade 680)
16	2	6562	Spring Washer
17	1	1959	.88" UNC Jam Nut
18	1	82535 (2)	Pivot Pin
19	2	82861	Double .50" Hose Clamp
	2	82859	Double .38" Hose Clamp
20	2	1514	.38" Flat Washer
21	2	1837	.38" UNC Deformed Lock Nut
22	1	83656	Handle Grip
23	1	84137	Guide Plate
24	2	1961	.38" UNC X .50" FlangeHead Hex Capscrew
25	1	34120	Hose Sock
26	1	53167	Hose Clamp
27	-	82552	Split Bushing (Included in Boom Assembly)

NOTES:

- (1) Pivot Pin #82534 is sold only in Pin Kit #86309. Kit includes one pin #82534, two thrust washers #6623 and two snap rings #1650.
- (2) Pivot Pin #82535 is sold only in Pin Kit #86307. Kit includes one pin #82535, two thrust washers #6623, two snap rings #1650 and one grease zerk #6616.
- (3) If replacing set screw style boom lock or boom lock handle you must order #86634, #86366 AND #1972.

ASSEMBLY #82623




ASSEMBLY #82623

<u>NO</u>	REQ'D	PART NO.	DESCRIPTION
1	-	6615	Self Aligning Bushing (Included in Cylinder Assembly)
2	1	117548 (2)	Bucket Cylinder Assembly (SN#314722 and UP)
•	2	6616	Grease Zerk
3	2	1021	.31" UNC X .75" Hex Capscrew
4	1 1	7448	SMV Clip (Used on Tractor Mounted Backhoes ONLY)
5 6	2	82741 1502	SMV Clip Mounting Plate .31" Lock Washer
7	2	1225	.31" UNC Hex Nut
8	2	1043	.38" UNC X 1.00" Hex Capscrew
9	3	1503	.38" Lock Washer
10	2	1226	.38" UNC Hex Nut
11	As Req'd	6623	Thrust Washer 1.38" X .031"
	As Req'd	64724	Thrust Washer 1.38" X .090"
	As Req'd	64725	Thrust Washer 1.38" X .125"
12	6	1650	Snap Ring
13	2	82533 (1)	Pivot Pin
14	1	1088	.50" UNC X 1.00" Hex Capscrew
15	1	1516	.50" Flat Washer
16	1	86149	Spacer Tube Pivot Pin
17 18	1	82416 82402	Bushing (2 Included in Dipper Assembly)
10	-	02402	(Installed with Locktite Grade 680)
19	As Req'd	6622	Thrust Washer 1.75" X .082
20	1	1651	Snap Ring
21	6	6616	Grease Zerk
22	1	82707	Dipper Assembly (Includes (2) 81610 & (2) 82402
23		02270	Bushings) (Bushings Installed with Locktite Grade 680)
23 24	-	83370 81610	Spacer Tube (Used in Dipper UP to SN #8288) Bushing (Included in Dipper Assembly)
24	-	01010	(Installed with Locktite Grade 680)
25	1	84914	Dipper Link Plate
26	1	83428	Dipper Link
27	1	82523	Bucket Link Assembly
			(Bucket Link Assembly UP TO SN #292 Included
			(2) 81610 Bushings, (4) 81828 Bushings, (1) 83368 Spacer, (2) 83369 Spacers)
28	2	1613	Cotter Pin
29	1	82580	Pivot Pin
30	1	82595	Pivot Pin
	-		

NOTE:

- (1) Pivot Pin #82533 is sold only in Pin Kit #86308. Kit includes one pin #82533, two thrust washers #6623 and two snap rings #1650.
- (3) When replacing the bucket cylinder on units up to SN #314721, two #38766 extension hoses must also be ordered.

ASSEMBLY #82469



ASSEMBLY #82469

NO	REQ'D	PART NO.	DESCRIPTION
1	-	6615	Self Aligning Bushing (Included in Cylinder Assembly)
2	1	85779	Dipper Cylinder Assembly
	2	6616	Grease Zerk
	2	3103	Straight Adapter
3	As Req'd	6623	Thrust Washer 1.38" X .031"
	As Req'd	64724	Thrust Washer 1.38" X .090"
	As Req'd	64725	Thrust Washer 1.38" X .125"
4	1	82476	Boom Cylinder Assembly
	1	6616	Grease Zerk
	2	3103	Straight Adapter
5	1	1043	.38" UNC X 1.00" Hex Capscrew
6	1	1503	.38" Lock Washer
7	1	82862	Clamp Plate
8	1	82863	Rubber Spacer
9	1	6616	Grease Zerk
10	-	86673	Bushing (Included in Boom Assembly)
11	1	82534 (1)	Pivot Pin
12	4	1650	Snap Ring
13	1	86634 ⁽³⁾	Boom Lock Handle
14	1	86366 (3)	Boom Lock
	1	1972 (3)	.38" X .50" Set Screw
15	1	82677	Boom Assembly (Includes (2) 82552 & (2) 86673
			Bushings - Installed with Locktite Grade 680)
16	2	6562	Spring Washer
17	1	1959	.88" UNC Jam Nut
18	1	82535 (2)	Pivot Pin
19	2	82859	Double Hose Clamp
20	2	1514	.38" Flat Washer
21	2	1837	.38" UNC Deformed Lock Nut
22	1	83656	Handle Grip
23	1	84137	Guide Plate
24	2	1961	.38" UNC X .50" Flange Head Hex Capscrew
25	1	34120	Hose Sock
26	1	53167	Hose Clamp
27	-	82552	Bushing (Included in Boom Assembly)


NOTES:

(1) Pivot Pin #82534 is sold only in Pin Kit #86309. Kit includes one pin #82534, two thrust washers #6623 and two snap rings #1650.

(2) Pivot Pin #82535 is sold only in Pin Kit #86307. Kit includes one pin #82535, two thrust washers #6623, two snap rings #1650 and one grease zerk #6616.

(3) If replacing set screw style boom lock or boom lock handle you must order #86634, #86366 AND #1972.

ASSEMBLY #82469




ASSEMBLY #82469

<u>NO</u>	REQ'D	PART NO.	DESCRIPTION
1 2	- 1 2	6615 117548 (2) 6616	Self Aligning Bushing (Included in Cylinder Assembly) Bucket Cylinder Assembly (SN#315228 and UP) Grease Zerk
3	2	1021	.31" UNC X .75" Hex Capscrew
4	1	7448	SMV Clip (Used on Tractor Mounted Backhoes ONLY)
5	1	82741	SMV Clip Mounting Plate
6	2	1502	.31" Lock Washer
7	2	1225	.31" UNC Hex Nut
8	2	1043	.38" UNC X 1.00" Hex Capscrew
9	2	1503	.38" Lock Washer
10	2 Ao Dog'd	1226	.38" UNC Hex Nut
11	As Req'd As Req'd	6623 64724	Thrust Washer 1.38" X .031" Thrust Washer 1.38" X .090"
	As Req'd	64725	Thrust Washer 1.38 X .125"
12	6	1650	Snap Ring
13	2	82533 (1)	Pivot Pin
14	1	1088	.50" UNC X 1.00" Hex Capscrew
15	1	1516	.50" Flat Washer
16	1	86149	Spacer Tube
17	1	82416	Pivot Pin
18	-	82402	Bushing (2 Included in Dipper Assembly)
			(Installed with Locktite Grade 680)
19	As Req'd	6622	Thrust Washer 1.75" X .082
20	1	1651	Snap Ring
21	6	6616	Grease Zerk
22	1	82682	Dipper Assembly (Includes (2) 81610 & (2) 82402 Bushings) (Bushings Installed with Locktite Grade 680)
23	-	83370	Spacer Tube (Used in Dipper UP to SN #8226)
24	-	81610	Bushing (Included in Dipper Assembly)
			(Installed with Locktite Grade 680)
25	1	84914	Dipper Link Plate
26	1	83428	Dipper Link
27	1	82523	Bucket Link Assembly (Bucket Link Assembly UP TO SN #292 Included (2) 81610 Bushings, (4) 81828 Bushings, (1) 83368 Spacer, (2) 83369 Spacers)
28	2	1613	Cotter Pin
29	1	82580	Pivot Pin
30	1	82595	Pivot Pin

NOTE:

- (1) Pivot Pin #82533 is sold only in Pin Kit #86308. Kit includes one pin #82533, two thrust washers #6623 and two snap rings #1650.
- (2) When replacing the bucket cylinder on units up to SN #315227, two #38766 extension hoses must also be ordered.




CONSOLE ASSEMBLY

ASSEMBLY #87442

<u>ITEM</u>	<u>REQ'D</u>	PART NO.	DESCRIPTION
1	2	83063	Ball Handle
2	2	81871	Control Handle
3	1	83235	Control Lever Boot
4	2	1242	.50" UNC Jam Nut
5	1	83409	Console Cover with Decals
6	1	83406	Ball Handle - RED
7	1	83273	Rod
8	1	82795	Spring
9	1	87288	Console
10 11 12 13 14 15	1 1 2 3 3 2	1476 5545 87147 1958 1926 1029 1089	.38-24" UNF Jam Nut Balljoint Cover Plate .25" UNC X .75" Hex Head Body Bolt .31" UNC U-Nut .31" UNC X 2.75" Hex Capscrew .50" UNC X 1.25" Hex Capscrew
16 17 18 19 20	4 4 1 4	1042 1503 1514 82999 1513	.38" UNC X .75" Hex Capscrew .38" Lock Washer .38" Flat Washer Seat Mounting .31" Flat Washer
21	4	1502	.31" Lock Washer
22	4	1021	.31" UNC X .75" Hex Capscrew
23	2	1516	.50" Flat Washer
24	2	1542	.50" UNC Lock Nut
25	1	6980	Seat
26	6	1958	.25" UNC X .75" Hex Head Body Bolt
27	1	1592	.38" UNF Lock Nut
<u>Replac</u>	ement Bol	t-On Steps for	<u>units built before June 1, 1999</u>
28	1	82818	Right Step (Located in Mainframe Assembly)
29	6	1925	.31" UNC X .75" Carriage Bolt
30	6	1502	.31" Lock Washer

- 31 6 1225 .31" UNC Hex Nut
- 32 1 82819 Left Step (Located in Mainframe Assembly)

VALVE ASSEMBLY ASSEMBLY #2232




7743 4-29-04-2


ASSEMBLY #2232

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	1	82608	Valve - 6 Spool - Gresen
2	2	3368	O'Ring Adapter 8MBo-4FP
2 3	2	3088	90° Adapter 4MP-6MJ Long
4	3	3487	O'Ring Adapter 10MBo-6FP
5	3	3180	90° Adapter 6MP-8MJ
6	1	82094	Special Fitting
7	1	3360	Needle Valve
8	1	37578	Plastic Tube .25" X 30"
			(Located in Console Assembly)
9	4	3283	90° Adapter 10MBo-8MJ
10	2	30142	90° SAE O'Ring Boss 8MBo-6MJ
11	2	3336	O'Ring Adapter 10MBo-4FP
12	-	45643	Restrictor with Spring109 Dia. Orifice (Included in Valve)
13	1	3001	90° Adapter 4MP-6MJ
14	1	30151	Straight Adapter
	-		(If Required to Extend Needle Valve Through Console)
15	1	3185	Needle Valve
16	1	3137	Male Connector 4MP-6MJ
17	1	3469	45° Elbow 6MJ-6FJX
17	I	3409	(Located in Mainframe Assembly & Used on Backhoes with SN#10067 & UP)

GRESEN VALVE ASSEMBLY 609 & 611 BACKHOE (509 & 511 BACKHOES UP TO SN #270215)




VALVE ASSEMBLY GRESEN INLET COVER



GRESEN INLET COVER

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	1	4710	Inlet Cover #10 Ports
2	1	3156	Plug
3	1	45625	WH Main Relief Valve Assembly @ 2500 PSI

GRESEN VALVE SECTION ASSEMBLY #45648 408 Dipper & Bucket Section 509, 511, 609, & 611 Dipper Section



GRESEN VALVE SECTION ASSEMBLY #45648 408 Dipper & Bucket Section 509, 511, 609, & 611 Dipper Section

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1 2 3 4	1 2 1 2	45667 45653 45652	Valve Section Housing Cylinder Port Relief Assembly @ 2500 PSI Spool Clevis Adapter Spool Seal Kit
5	1		Spool
6	1	45282	Spool Positioner Assembly

INCLUDED IN VALVE ASSEMBLY BUT NOT IN VALVE SECTION

1	45546	Restrictor with Spring095 Dia. Orifice
		(Used in 408 Dipper Section - Top Port)
1	45633	Restrictor with Spring076 Dia. Orifice
		(Used in 408 Bucket Section - Bottom Port)


NOTES:

Items without part numbers are not sold separately.

Valve Section Seal Kit #4653 contains (3) Exhaust Passage O-Ring Seals and 2) Pressure Passage O-Ring Seals.

Complete Section Service Seal Kit #4719 includes ALL seals needed to service one complete valve section.

GRESEN VALVE SECTION ASSEMBLY #45649 509, 511, 609, & 611 Bucket Section



GRESEN VALVE SECTION ASSEMBLY #45649 509, 511, 609, & 611 Bucket Section

<u>ITEM</u>	<u>REQ'D</u>	PART NO.	DESCRIPTION
1 2 3 4 5	1 1 2 1	45669 45653 45652	Valve Section Housing Cylinder Port Relief Assembly @ 3500 PSI Spool Clevis Adapter Spool Seal Kit Spool
6 7	1 1	45282 4673	Spool Positioner Assembly Load Check Plug Assembly


NOTES:

Items without part numbers are not sold separately.

Valve Section Seal Kit #4653 contains (3) Exhaust Passage O-Ring Seals and (2) Pressure Passage O-Ring Seals.

Complete Section Service Seal Kit #4719 includes ALL seals needed to service one complete valve section.

GRESEN VALVE STABILIZER SECTION ASSEMBLY #4704



GRESEN VALVE STABILIZER SECTION ASSEMBLY #4704

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1 2 3 4 5	1 2 2 1 1	4819 45652 45282	Valve Section Housing Lockout Check Assembly Spool Seal Kit Spool Spool Positioner Assembly
6	1	45654	Unlocking Piston


NOTES:

Items without part numbers are not sold separately.

Valve Section Seal Kit #4653 contains (3) Exhaust Passage O-Ring Seals and (2) Pressure Passage O-Ring Seals.

Complete Section Service Seal Kit #4719 includes ALL seals needed to service one complete valve section.

GRESEN VALVE SECTION ASSEMBLY #45666 509, 511, 609, & 611 Swing Section



GRESEN VALVE SECTION ASSEMBLY #45666 509, 511, 609, & 611 Swing Section

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	1		Valve Section Housing
2	2	45670	Cylinder Port Relief / Anti-Cav.
3	1	45653	Check Assembly @ 2500 PSI Spool Clevis Adapter
4	2	45652	Spool Seal Kit
5	1		Spool
6	1	45282	Spool Positioner Assembly
7	2	45633	Port Restrictor with Spring
			.076 Dia. Orifice


NOTES:

Items without part numbers are not sold separately.

Valve Section Seal Kit #4653 contains (3) Exhaust Passage O-Ring Seals and (2) Pressure Passage O-Ring Seals.

Complete Section Service Seal Kit #4719 includes ALL seals needed to service one complete valve section.

GRESEN VALVE SECTION ASSEMBLY #45650 509, 511, 609, & 611 Boom Section



GRESEN VALVE SECTION ASSEMBLY #45650 509, 511, 609, & 611 Boom Section

<u>ITEM</u>	<u>REQ'D</u>	PART NO.	DESCRIPTION
1	1		Valve Section Housing
2	2	45668	Cylinder Port Relief Assembly @ 3000 PSI
3	1	45653	Spool Clevis Adapter
4	2	45652	Spool Seal Kit
5	1		Spool
6	1	45282	Spool Positioner Assembly
7	2		
1	2	45643	Port Restrictor with Spring .109 Dia. Orifice


NOTES:


Items without part numbers are not sold separately.

Valve Section Seal Kit #4653 contains (3) Exhaust Passage O-Ring Seals and (2) Pressure Passage O-Ring Seals.

Complete Section Service Seal Kit #4719 includes ALL seals needed to service one complete valve section.

VALVE ASSEMBLY **GRESEN OUTLET COVER**





TORQUE TO 20 ft. lbs.

VALVE ASSEMBLY GRESEN OUTLET COVER

ITEM <u>REQ'D</u> PART NO. DESCRIPTION 1 1 4690 **Outlet Cover** 2 Open Center Plug Assembly 1 4691 (Includes Open Center Plug & Main O-Ring Seal #4693) 3 1 3234 Plug


OPTIONAL

4	-	6977	Closed Center Plug Assembly (Includes Main O-Ring Seal #4693)
5	-	4698	Power Beyond Sleeve Assembly (Includes Main O-Ring Seal #4693)

NOTES:

Valve Section Seal Kit #4653 contains (3) Exhaust Passage O-Ring Seals and (2) Pressure Passage O-Ring Seals.


LEFT MECHANICAL JOYSTICK ASSEMBLY #45655 RIGHT MECHANICAL JOYSTICK ASSEMBLY #45656



LEFT MECHANICAL JOYSTICK ASSEMBLY #45655 RIGHT MECHANICAL JOYSTICK ASSEMBLY #45656

<u>ITEM</u>	<u>REQ'D</u>	PART NO.	DESCRIPTION
1	1	45657	Mounting Plate
2	2	1943	Screw
3	1	45664	Rod End
4	1	45662	Mechanical Slide
5	1	1945	Screw
6	3	1944	Screw
7	1	45658	Bracket - Left
	1	45659	Bracket - Right
8	1	45661	Rod End Stud
9	1	1271	Screw
10	3	45660	Spacer
11	3	1942	Lock Nut
12	1	45663	Handle Plate Assembly
10	4	45074	(Includes Items #13 through #17)
13	1	45671	Mechanical Joystick Plate
14	1	1087	Screw
15	2	45664	Female Rod End
16	1	45672	Handle Adapter
17	2	1271	Screw

HORIZONTAL HANDLE AND BRACKET ASSEMBLY #45586




HORIZONTAL HANDLE AND BRACKET ASSEMBLY #45586


<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	1	*	Handle
2	3	*	Cotter Pin
3	1	*	Pin
4	1	*	Link
	1	*	Link Plate
5	2	*	Screw
6	1	*	Bracket

* NOTE: All parts marked with an asterisk (*) are included in Horizontal Handle and Bracket Assembly #45586. Parts are not sold separately.


VALVE ASSEMBLY GRESEN VALVE SERVICE PARTS




Spool Positioner Assembly




Load Check Plug Assembly





Cylinder Port Relief Assembly




Cylinder Port Relief Assembly







Lockout Check Assembly




WH Main Relief Valve Assembly

GRESEN VALVE SERVICE PARTS

NO	<u>PART NO.</u>	DESCRIPTION
1	45282	Spool Positioner Assembly
		a Bonnet
		b Spring
		c Spring Collar
		d Spool Spud
		e Screw
2	4673	Load Check Plug Assembly (Seal Kit #4822)
		a Plug
		b O-Ring Seal
		c Backup Ring
		d O-Ring Seal
		e Backup Ring
		f O-Ring Seal
		g Spring
		h Poppet
3	45667	Cylinder Port Relief Assembly @ 2500 PSI
	45668	Cylinder Port Relief Assembly @ 3000 PSI
	45669	Cylinder Port Relief Assembly @ 3500 PSI
	•	close tolerances only the seals may be serviced in the field.)
	4822	Seal Kit
		a O-Ring Seal
		b Backup Ring
		c O-Ring Seal
		d Backup Ring
4	45070	e O-Ring Seal
4	45670	Relief/Anti-Cav. Check Assembly @ 2500 PSI
	(Due to) 4822	close tolerances only the seals may be serviced in the field.) Seal Kit
	4022	
		a O-Ring Seal b Backup Ring
		c O-Ring Seal
		d Backup Ring
		e O-Ring Seal
5	4819	Lockout Check Assembly
0		close tolerances only the seals may be serviced in the field.)
	4829	Seal Kit
		a O-Ring Seal
		b Backup Ring
		c O-Ring Seal
		d Backup Ring
6	45633	Port Restrictor Assembly .076 Dia. Orifice
	45643	Port Restrictor Assembly .109 Dia. Orifice
		a Spring
		b Orifice Plate
7	45625	WH Main Relief Valve Assembly @ 2500 PSI
(Due t	to close tolerance	s only the seals may be serviced in the field.)
	45142	Seal Kit
		a O-Ring Seal
		b Backup Ring
		c O-Ring Seal
		d O-Ring Seal


OPTIONAL SWING SPEED CONTROL



OPTIONAL SWING SPEED CONTROL

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	1	3185	Needle Valve
2	1	3137	Male Connector
3	1	4247	Swing Speed Control Decal


OPTIONAL STEP ASSEMBLY



OPTIONAL STEP ASSEMBLY

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	1	83651	Step
2	2	1045	.38" UNC X 1.50" Hex Capscrew
3	2	1503	.38" Lock Washer
4	2	1226	.38" UNC Hex Nut

CYLINDER ASSEMBLY SWING CYLINDER ASSEMBLY #81022




6847 2-14-96

SWING CYLINDER ASSEMBLY #81022

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1 2 3 4 5	1 1 2 1 1	81024 77441 82441 81023 82578	Cylinder Rod Cylinder Gland Needle Bearing Cylinder Tube Piston
6 7 8 9 10	1 1 1 1	1483 62523 45389* 4570* 45219*	Hex Nut Self Aligning Bushing Rod Wiper O'Ring Poly Pak Seal
11 12 13 14 15	1 1 1 1 1	45249* 45557* 5421 4641* 45251*	Back-Up Ring O'Ring Washer O'Ring Piston Ring
16	1	45250*	O'Ring

NOTE: Seal Kit #45551 Includes all parts marked with an asterisk (*). Parts are not sold separately.

CYLINDER ASSEMBLY STABILIZER CYLINDER ASSEMBLY #82980



6849 2-14-96


STABILIZER CYLINDER ASSEMBLY #82980

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1 2 3 4	1 1 1 1	82981 1483 87170 77445	Cylinder Tube Hex Nut Piston Cylinder Gland
5	1	82986	Cylinder Rod
6 7 8 9 10	1 1 1 1	45744* 45743* 4641* 45555* 4631*	O'Ring Piston Ring O'Ring O'Ring Back-Up Ring
11 12 13	1 1 1	45225* 4908* 45372*	Poly Pak Seal O'Ring Rod Wiper

NOTE: Seal Kit #45746 includes all parts marked with an asterisk (*). Parts are not sold separately.

6850 9-30-04-2

511 & 609 BOOM CYLINDER ASSEMBLY #82625




511 & 609 BOOM CYLINDER ASSEMBLY #82625

<u>ITEM</u>	<u>REQ'D</u>	PART NO.	DESCRIPTION
1	1	82635	Cylinder Tube
2	1	1483	Hex Nut
3	1	82793	Piston
4	1	77445	Cylinder Gland
5	1	82636	Cylinder Rod
6	2	6615	Self Aligning Bushing
7	1	4570*	O'Ring
8	1	4569*	Piston Ring
9	1	4641*	O'Ring
10	1	45555*	O'Ring
11	1	4631*	Back-Up Ring
12	1	45225*	Poly Pak Seal
13	1	4908*	O'Ring
14	1	45372*	Rod Wiper

NOTE: Seal Kit #45550 includes all parts marked with an asterisk (*). Parts are not sold separately.

CYLINDER ASSEMBLY 611 BOOM CYLINDER ASSEMBLY #82476




611 BOOM CYLINDER ASSEMBLY #82476

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	1	82481	Cylinder Tube
2	1	1483	Hex Nut
3	1	82817	Piston
4	1	77451	Cylinder Gland
5	1	82482	Cylinder Rod
6	2	6615	Self Aligning Bushing
7	1	45245*	O'Ring
8	1	45244*	Piston Ring
9	1	4641*	O'Ring
10	1	45242*	O'Ring
11	1	45243*	Back-Up Ring
12	1	45119*	Poly Pak Seal
13	1	45412*	O'Ring
14	1	45370*	Rod Wiper

NOTE: Seal Kit #45415 includes all parts marked with an asterisk (*). Parts are not sold separately.

609 DIPPER CYLINDER ASSEMBLY #85782

SERIAL #---8289 AND UP



609 DIPPER CYLINDER ASSEMBLY #85782


SERIAL #---8289 AND UP

<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	85783	Cylinder Tube
1	1484	Hex Nut
1	85737	Piston
1	77447	Cylinder Gland
1	82626	Cylinder Rod
2	6615	Self Aligning Bushing
1	4908*	O'Ring
1	4909*	Piston Ring
1	4865*	O'Ring
1	45559*	O'Ring
1	4790*	Back-Up Ring
1	45119*	Poly Pak Seal
1	45245*	O'Ring
1	45370*	Rod Wiper
	1 1 1 1 2 1 1 1	$\begin{array}{cccccccccccccccccccccccccccccccccccc$

NOTE: Seal Kit #45375 includes all parts marked with an asterisk (*). Parts are not sold separately.

SERVICE PARTS ONLY - 609 DIPPER CYLINDER ASSEMBLY #82624

UP TO SERIAL #---8289



SERVICE PARTS ONLY - 609 DIPPER CYLINDER ASSEMBLY #82624

UP TO SERIAL #---8289


<u>NO</u>	<u>REQ'D</u>	PART NO.	DESCRIPTION
1	1	82628	Cylinder Tube - SEE NOTE
2	1	1484	Hex Nut
3	1	68926	Piston - SEE NOTE
4	1	77447	Cylinder Gland
5	1	82626	Cylinder Rod
6	2	6615	Self Aligning Bushing
7	1	4908*	O'Ring
8	1	4909*	Piston Ring
9	1	4865*	O'Ring
10	1	45559*	O'Ring
11	1	4790*	Back-Up Ring
12	1	45119*	Poly Pak Seal
13	1	45245*	O'Ring
14	1	45370*	Rod Wiper

NOTE: Seal Kit #45375 includes all parts marked with an asterisk (*). Parts are not sold separately.

NOTE: If ordering a complete new dipper cylinder order assembly #85782. The dipper cylinder #82624 (serial #---8288 or before) can be upgraded to the new dipper cylinder #85782 by replacing the cylinder tube and piston (Items #1 & #3) with cylinder tube #82783 and piston #85737.

611 DIPPER CYLINDER ASSEMBLY #85779

SERIAL #---8227 AND UP



611 DIPPER CYLINDER ASSEMBLY #85779


SERIAL #---8227 AND UP

<u>NO</u>	REQ'D	PART NO.	DESCRIPTION
1	1	85780	Cylinder Tube
2	1	1483	Hex Nut
3	1	85461	Piston
4	1	77451	Cylinder Gland
5	1	82495	Cylinder Rod
6	2	6615	Self Aligning Bushing
7	1	45245*	O'Ring
8	1	45244*	Piston Ring
9	1	4641*	O'Ring
10	1	45242*	O'Ring
11	1	45243*	Back-Up Ring
12	1	45119*	Poly Pak Seal
13	1	45412*	O'Ring
14	1	45370*	Rod Wiper

NOTE: Seal Kit #45415 includes all parts marked with an asterisk (*). Parts are not sold separately.

SERVICE PARTS ONLY - 611 DIPPER CYLINDER ASSEMBLY #82478

UP TO SERIAL #---8227



SERVICE PARTS ONLY - 611 DIPPER CYLINDER ASSEMBLY #82478


UP TO SERIAL #---8227

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	1	82494	Cylinder Tube - SEE NOTE
2	1	1483	Hex Nut
3	1	64397	Piston - SEE NOTE
4	1	77451	Cylinder Gland
5	1	82495	Cylinder Rod
6	2	6615	Self Aligning Bushing
7	1	45245*	O'Ring
8	1	45244*	Piston Ring
9	1	4641*	O'Ring
10	1	45242*	O'Ring
11	1	45243*	Back-Up Ring
12	1	45119*	Poly Pak Seal
13	1	45412*	O'Ring
14	1	45370*	Rod Wiper

NOTE: Seal Kit #45415 includes all parts marked with an asterisk (*). Parts are not sold separately.

NOTE: If ordering a complete new dipper cylinder order assembly #85779. The dipper cylinder #82478 (serial #---8226 or before) can be upgraded to the new dipper cylinder #85779 by replacing the cylinder tube and piston (Items #1 & #3) with cylinder tube #85780 and piston #85461.

CYLINDER ASSEMBLY BUCKET CYLINDER ASSEMBLY #117548



BUCKET CYLINDER ASSEMBLY #117548

<u>ITEM</u>	<u>REQ'D</u>	PART NO.	DESCRIPTION
1	1	117549	Cylinder Tube (See Note)
2	1	1484	Hex Nut
3	1	55904	Piston
4	1	77444	Cylinder Gland
5	1	82506	Cylinder Rod
6	2	6615	Self Aligning Bushing
7	1	4570*	O'Ring
8	1	4569*	Piston Ring
9	1	4865*	O'Ring
10	1	45555*	O'Ring
11	1	4631*	Back-Up Ring
12	1	45117*	Poly Pak Seal
13	1	4908*	O'Ring
14	1	45364*	Rod Wiper


NOTE: Seal Kit #45547 includes all parts marked with an asterisk (*). Parts are not sold separately.

NOTE: The hydraulic ports on the cylinder tube have been relocated towards the center of the cylinder. When replacing the cylinder tube and your existing cylinder hydraulic ports are located at the end of the cylinder tube, two #38766 extension hoses must also be ordered.

MAINFRAME HOSE SET

ASSEMBLY #82761

SN #100067 AND UP



7745 6-17-99

MAINFRAME HOSE SET

ASSEMBLY #82761

SN #10067 AND UP

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	4	37553	Hose Assembly 25" X 58" 6FJX-6FJX
2	1	37700	Hose Assembly 25" X 12" 6FJX-6FJX 45° Gooseneck
3	2	37552	Hose Assembly 25" X 14.50" 6FJX-6FJX
4	1	37699	Hose Assembly 25" X 17.00" 6FJX-6FJX

NOTE: Refer to the mainframe assembly for the priority valve hoses which are included in this assembly but have been shown in the mainframe assembly for clarity.


NOTE: Letters on the hose set diagram show the hydraulic hose routing between the backhoe control valve and the various hydraulic cylinders. Simply match the letter on the control valve port to the same letter on the hydraulic hose ends. Example: Hose Assembly labeled "C" runs from the upper Left Stabilizer port on the hydraulic control valve - through the mainframe and to the barrel end fitting on the left stabilizer cylinder.

NOTE: The fittings on the hydraulic cylinders have been altered for clarity purposes. This will assist you in distinguishing between the rod end and the barrel end of the various hydraulic cylinders.

MAINFRAME HOSE SET

ASSEMBLY #82761

UP TO SN #100067



MAINFRAME HOSE SET

ASSEMBLY #82761

UP TO SN #10067

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	4	37553	Hose Assembly 25" X 58" 6FJX-6FJX
2	1	37522	Hose Assembly 25" X 16.35" 6FJX-6FJX 90° Gooseneck
3	2	37552	Hose Assembly .25" X 14.50" 6FJX-6FJX
4	1	37644	Hose Assembly 25" X 17.50" 6FJX-6FJX 90° Short Gooseneck


NOTE: Refer to the mainframe assembly for the priority valve hoses which are included in this assembly but have been shown in the mainframe assembly for clarity.


NOTE: Letters on the hose set diagram show the hydraulic hose routing between the backhoe control valve and the various hydraulic cylinders. Simply match the letter on the control valve port to the same letter on the hydraulic hose ends. Example: Hose Assembly labeled "C" runs from the upper Left Stabilizer port on the hydraulic control valve - through the mainframe and to the barrel end fitting on the left stabilizer cylinder.

NOTE: The fittings on the hydraulic cylinders have been altered for clarity purposes. This will assist you in distinguishing between the rod end and the barrel end of the various hydraulic cylinders.

ASSEMBLY #82762

HYDRAULIC CONTROL VALVE





6845 9-11-98-3

ASSEMBLY #82762


<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION	
1	2	37558	Hose Assembly 8FJX-8FJX	.38" X 93"
2	2	38760	Hose Assembly 8FJX-8FJX	.38" X 147"
3	2	37569	Hose Assembly 8FJX-8FJX	.38" X 135"


NOTE: Letters on the hose set diagram show the hydaulic hose routing between the backhoe control valve and the various hydraulic cylinders. Simply match the letter on the control valve port to the same letter on the hydraulic hose ends. Example: Hose Assembly labeled "G" runs from the lower Boom port on the hydraulic control valve - through the mainframe and swing post and to the rod end of the boom cylinder.

NOTE: The fittings on the hydraulic cylinders have been altered for clarity purposes. This will assist you in distinguishing between the rod end and the barrel end of the various hydraulic cylinders.

ASSEMBLY #82763

HYDRAULIC CONTROL VALVE







ASSEMBLY #82763

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION	
1	2	37558	Hose Assembly 8FJX-8FJX	.38" X 93"
2	2	37559	Hose Assembly 8FJX-8FJX	.38" X 157"
3	2	38759	Hose Assembly 8FJX-8FJX	.38" X 165"

NOTE: Letters on the hose set diagram show the hydaulic hose routing between the backhoe control valve and the various hydraulic cylinders. Simply match the letter on the control valve port to the same letter on the hydraulic hose ends. Example: Hose Assembly labeled "G" runs from the lower Boom port on the hydraulic control valve - through the mainframe and swing post and to the rod end of the boom cylinder.

NOTE: The fittings on the hydraulic cylinders have been altered for clarity purposes. This will assist you in distinguishing between the rod end and the barrel end of the various hydraulic cylinders.





STABILIZER PADS

FLAT STABILIZER PAD ASSEMBLY - #83055

<u>NO</u>	<u>REQ'D</u>	PART NO.	DESCRIPTION
1	2	83079	Flat Stabilizer Pad

LARGE GROUSER PAD ASSEMBLY - #83057

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
2	2	83086	Large Grouser Pad

GROUSER PAD ASSEMBLY - #83054


<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
3	2	83059	Grouser Stabilizer Pad

RUBBER STABILIZER PAD ASSEMBLY - #83056

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
4	2	83084	Rubber Stabilizer Pad Assembly (Includes Items 5 through 11)
5	1	83085	Stabilizer Pad
6	4	1226	.38" UNC Hex Nut
7	4	1503	.38" Lock Washer
8	2	1514	.38" Flat Washer
9	1	51190	Slide Plate
10	1	64412	Rubber Strip Bundle
11	2	1661	.38" UNC X 11.50" Readi Bolt

STABILIZER PADS

FLIP-OVER STABILIZER PAD ASSEMBLY #83091 (COMPLETE SET OF (2) FLIP-OVER PADS - ASSEMBLY #83058)




STABILIZER PADS

FLIP-OVER STABILIZER PAD ASSEMBLY #83091 (COMPLETE SET OF (2) FLIP-OVER PADS - ASSEMBLY #83058)

<u>ITEM</u>	<u>REQ'D</u>	PART NO.	DESCRIPTION
1	1	84496	Flip-Over Pad
2	2	84495	Spacer
3	2	1652	1.25" Snap Ring
4	VARIES	57693	Thrust Washer 1.25" X .078"
	VARIES	64727	Thrust Washer 1.25" X .125"
5	1	83096	Pin
6	6	1837	.38" UNC Hex Deformed Lock Nut
7	6	1514	.38" Flat Washer
8	3	51190	Slide Plate
9	1	64412	Rubber Strip Bundle
10	4	1053	.38" UNC X 3.50" Hex Capscrew
11	2	1057	.38" UNC X 5.00" Hex Capscrew

STABILIZER CYLINDER COVER ASSEMBLY #83851




OPTIONAL STABILIZER CYLINDER COVER

STABILIZER CYLINDER COVER ASSEMBLY #83851

<u>NO</u>	<u>REQ'D</u>	<u>PART NO.</u>	DESCRIPTION
1	2	83852	Stabilizer Cylinder Cover with Decal
2	2	4167	No Step Decal
3	2	83906	Muffler Clamp Assembly
4	2	83856	Guide Ring
5	4	1575	.38" UNC X .50" Set Screw

BUCKET ASSEMBLIES

POWER DIG BUCKETS



6861 3-8-96

BUCKET ASSEMBLIES

POWER DIG BUCKETS

<u>NO</u>	REQ'D	PART NO.	DESCRIPTION
1	8	6355	Bushing
2	1	67412 67416 67418 67420 67424	12" Bucket Weldment 16" Bucket Weldment 18" Bucket Weldment 20" Bucket Weldment 24" Bucket Weldment
3	1	67399 67393 67387 67338 66387	12" Replacement Front Cutter Edge 16" Replacement Front Cutter Edge 18" Replacement Front Cutter Edge 20" Replacement Front Cutter Edge 24" Replacement Front Cutter Edge
4 5 6	Varies Varies Varies	55090 55088 56073	Replacement Tooth Shank Replacement Tooth Point Replacement Tooth Point and Shank Assembly
7 8	1 1	68482 6616	Spacer Grease Zerk
9	Optional	82948	Bell Hole Bucket Link (Requires 3 Grease Zerks - Part #6616)
10	1 1	67151 67152	Left Replacement Side Cutter Right Replacement Side Cutter


NOTE:

Power dig buckets have three different bucket link positions for different digging needs.


Position "A" power digging position for added digging force in hard ground.

Position "B" truck loading position for greater ease of spoil removal and higher dump height.

Position "C" standard digging position with a good balance of digging force and bucket rotation for general digging use.



OLD STYLE BUCKET



BUCKET ASSEMBLIES SEVERE DUTY BUCKETS

BUCKET ASSEMBLIES

SEVERE DUTY BUCKETS

NOTE: ALL SEVERE DUTY BUCKETS HAVE BEEN REPLACED WITH A NEW BUCKET WELDMENT WHICH INCLUDES A STRAIGHT FRONT CUTTING EDGE AND MORE AGGRESSIVE SIDE CUTTERS. WHEN OR-DERING REPLACEMENT CUTTING EDGES FOR THE OLDER STYLE BUCKETS PLEASE REFER TO ITEMS #9 AND #10.

<u>ITEM</u>	<u>REQ'D</u>	PART NO.	DESCRIPTION	
1	Optional	82948	Bell Hole Bucket Link (Requires 3 Grease Zerks #6616)	
2	8	6355	Bushing (500 & 600 Series Backhoes)	
3	1	6616	Grease Zerk	
4	1	68482	Spacer	
5	1	103312	12" Bucket Weldment	
		103316	16" Bucket Weldment	
		103318	18" Bucket Weldment	
		103320	20" Bucket Weldment	
		103324	24" Bucket Weldment	
6	1	102875	Left Replacement Side Cutter	
	1	102874	Right Replacement Side Cutter	
7	1	102866	12" Replacement Front Cutter Edge	
		102867	16" Replacement Front Cutter Edge	
		102868	18" Replacement Front Cutter Edge	
		102869	20" Replacement Front Cutter Edge	
		102870	24" Replacement Front Cutter Edge	
8	Varies	85003	Replacement Tooth Point and Shank Assembly	
		74228	Replacement Tooth Shank (Weld On)	
		84863	Replacement Tooth (Bolt On)	
		74227	Spiral Roll Pin	

OLD STYLE SEVERE DUTY BUCKETS


9	1	67151	Left Replacement Side Cutter
	1	67152	Right Replacement Side Cutter
10	1	85236	12" Replacement Front Cutter Edge
		85241	16" Replacement Front Cutter Edge
		85246	18" Replacement Front Cutter Edge
		85251	20" Replacement Front Cutter Edge
		85256	24" Replacement Front Cutter Edge

NOTE:

Severe duty buckets have three different bucket link positions for different digging needs. Position "A" digging position for added digging force in hard ground.

Position "B" truck loading position for greater ease of spoil removal and higher dump height. Position "C" standard digging position with a good balance of digging force and bucket rotation for general digging use.

ASSEMBLY #83758




6863 6-22-99-2

ASSEMBLY #83758

NO	REQ'D	<u>PART NO.</u>	DESCRIPTION
1	1	45375	Soci Kit (Dinner Cydinder)
I	I		Seal Kit (Dipper Cylinder)
	1	45547	Seal Kit (Bucket Cylinder)
	2	45550	Seal Kit (Boom/Stabilizer Cylinders)
	1	45551	Seal Kit (Swing Cylinder)
2	2	81610	Bushing
	2	6355	Bushing
3	4	6616	Grease Zerk
4	4	84863	Severe Duty Bucket Tooth
5	4	1650	Snap Ring 1.38"
6	4	6623	Thrust Washer 1.38" X .031"
7	1	65349	Cylinder Seal Install Tool
8	2	1613	Cotter Pin

ASSEMBLY #83759



6876 6-22-99-2


ASSEMBLY #83759


<u>NO</u>	REQ'D	PART NO.	DESCRIPTION
1	2	45415	Seal Kit (Boom/Dipper Cylinder)
	1	45547	Seal Kit (Bucket Cylinder)
	1	45550	Seal Kit (Stabilizer Cylinders)
	1	45551	Seal Kit (Swing Cylinder)
2	2	81610	Bushing
	2	6355	Bushing
3	4	6616	Grease Zerk
4	4	84863	Severe Duty Bucket Tooth
5	4	1650	Snap Ring 1.38"
6	4	6623	Thrust Washer 1.38" X .031"
7	1	65349	Cylinder Seal Install Tool
8	2	1613	Cotter Pin

DECALS DECAL PLACEMENT

GENERAL INFORMATION

The diagrams on this page shows the location of all the decals used on the 609 and 611 backhoes. The decals are identified by their part numbers, with reductions of the actual decals located on the following pages. Use this information to order replacements for lost or damaged decals. Be sure to read all decals before operating the backhoe. They contain information you need to know for both safety and backhoe longevity.








PART #40092 (3 REQ'D) BRADCO LOGO



PART #40247 (2 REQ'D) 609 MODEL NUMBER



PART #4271 INLINE FILTER DECAL

6858 10-19-12-3



HIGH-PRESSURE FLUID HAZARD

- To prevent serious injury or death:
- Relieve pressure on system before repairing or adjusting or disconnecting.
- Wear proper hand and eye protection when searching for leaks. Use wood or cardboard instead of hands.
- Keep all components in good repair.

PART #40151 HIGH PRESSURE FLUID DECAL



PART #41169 **DANGER! BACKHOE SECURE**

IMPORTANT

TO PREVENT BACKHOE DAMAGE:

DO NOT ATTACH TOW CHAIN TO DIPPER OR BUCKET.

DO NOT REPEATEDLY SLAM SWING POST INTO SWING STOPS.

PREPARATION FOR STORAGE

LUBRICATE ALL GREASE POINTS. LEAVE AS MANY CYLINDERS IN CLOSED POSITION AS POSSIBLE. COVER ALL EXPOSED CYLINDER RODS WITH A LIGHT COAT OF GREASE. #40257

PART #40257 **IMPORTANT! DECAL**



TO PREVENT SERIOUS INJURY **OR DEATH:**


- Do not operate or work on this machine without reading and understanding Operator's Manual.
- Avoid unsafe operation or maintenance.
- Do not operate machine with guards and covers removed.
- This machine was designed to be operated by one operator. Do not carry passengers on unit.
- Before installing backhoe on your unit extend boom and dipperstick and lower bucket to ground.
- Never use backhoe as manlift.
- Operate backhoe control levers from operator's seat only. Lower stabilizers and bucket to ground before leaving operator's seat.
- Engage boom lock and swing lock before transporting backhoe.

#40255

PART #40255 **OPERATIONAL WARNING DECAL**



PART #40149 **DANGER! PINCH POINTS**




PART #4368 OPERATING CONTROLS DECAL


PETCOCK

OPEN TO RELIEVE PRESSURE WHEN HOOKING UP HYDRAULIC COUPLERS. Always close petcock before Operating backhoe. 4170


PART #4170 PETCOCK OPERATION DECAL



PART #4247 SWING SPEED CONTROL DECAL



PART #40219 BOOM LOCK DECAL



PART #40249 SWING LOCK DECAL

IMPORTANT

The backhoe bucket is capable of contacting this stabilizer and/or cylinder. Careful operation will avoid backhoe damage.

PART #4140 BUCKET CONTACT WARNING DECAL



PART #4338 MADE IN U.S.A. DECAL



PART #40440 CALL BEFORE YOU DIG



PART #4084 GREASE 8 HOURS